

Furrow Cruiser Case IH Conversion Kit Installation Instructions



1. Remove single packing wheel by taking the middle bolt out.
2. Slightly loosen the four small bolts on the top of the closing wheel arm. *(This will allow the bracket to slide on easily)*
3. Slide on the Conversion bracket so that the top holes line up with the packing wheel arm's holes. *(Make sure the bracket is on correctly so that the wheels will have the correct angle-You may have to tap on.)*
4. Insert the 2 small bolts from the inside out and tighten the nuts. Your bracket should be secure to the closing wheel arm.
5. Tighten the four small bolts on the top of the closing wheel arm.
6. Slide the bushing inside the bottom of the bracket and hold it between the holes. Insert the bolt, Furrow Cruiser Complete Wheel, washer from the inside out and tighten the nut. Do this on each side.

For questions or inquiries, give us a call at 605-528-3333

